Model	BA300
Weight Capacity	400 lbs.
Maximum Speed ¹	Up to 14 mph
Ground Clearance ³	3.5" at center of frame,1.37" at anti-tip,6.18" at highest point
Turning Radius ³	60″
Overall Length ³	59″
Overall Width ³	27.12"
Seat-to-Ground Height ³	28″
Seat-to-Deck Height ³	19″
Front Tires ³	3" x 16" tubeless pneumatic
Rear Tires ³	3" x 16" tubeless pneumatic
Suspension	Front and rear
Range Per Charge ^{1,2}	Up to 19 miles at 400 lbs. at full speed Up to 31 miles at 220 lbs. at low speed
Total Weight ⁵	Without batteries: 212.8 lbs. With batteries: 318.8 lbs.
Standard Seating ³	Type: Limited reclining high back with sliders Weight: 45.6 lbs. Material: Black vinyl Dimensions: Width: 20", Depth: 18"
Drive System	Rear-wheel drive sealed transaxle with 24-volt DC motor
Dual Braking System	Regenerative and electromechanical
Battery Requirements ^{4,6}	Size: (2) 75 AH Weight: 53 lbs each
Battery Charger	8 amp, off-board
Warranty	Frame: lifetime limited Drivetrain: 2-year limited Electronics: 2-year limited Battery: 6-months

**Non-Medical Device

This product is not a medical device and is not intended to assist, treat, diagnose, or alleviate any medical condition or disability.

- 1 Varies with user weight, terrain type, battery amp-hour (AH), battery charge, battery condition, and tire condition. This specification can be subject to a variance of (+ or -) 10%.
- 2 Tested in accordance with ANSI/RESNA, MC Vol2, Section 4 & ISO 7176-4 standards. Results derived from theoretical calculations based on battery specifications and drive system performance. Test conducted at maximum weight capacity.
- 3 Due to manufacturing tolerances and continual product improvement, this specification can be subject to a variance of (+ or -) 3%.
- 4 Battery weight may vary based on battery manufacturer.
- 5 Includes standard seat weight.
- 6 AGM or gel cell type required.



(US) 800-800-8586 • (Canada) 888-570-1113 bajamobility.com | ⓒ ি ⓒ ি

NOTE: All specifications subject to change without notice. The information contained herein is correct at the time of publication; we reserve the right to alter specifications without prior notice. Speed and range vary with user weight, terrain type, battery charge, battery condition and tire pressure. Due to manufacturing tolerances and continual product improvement, length, width, turning radius and ground clearance can be subject to variance of + or - 3 %. Special order seats or non-standard dimensions will not be fold-flat and depth-adjustable.



GET OUTDOORS






Enjoy fast speed and advanced safety features, all in one sleek package! The Baja[™] Raptor 2 cruises up to 14 mph and is equipped with a full LED lighting package and a regenerative braking system.

Features

- Adjustable thumb throttle
- Hand brake with regenerative braking system
- 60" turning radius
- 19 miles per charge at 400 lbs. (31 miles at 220 lbs.)
- Full LED light package includes LED headlights, directional signals and brake lights that offer full visibility for increased safety
- Easy-to-read LCD console shows fast/slow speed mode, estimated speed, mileage and battery display
- Secure, lockable under seat storage compartment with seat support rod
- Sleek and solid design for enhanced stability
- Front and rear suspension
- Front storage compartment located on the tiller
- Tubeless pneumatic tires for a smooth ride
- XLR USB charger



Accessories*

- 50-90" lap belt
- Cane/crutch holder
 - (single, double)
- Cup holder

Military Patches



*Only one rear accessory can be used at a time.

- Rear basket
 - Saddle bag
 - Safety flag
 - Walker holder
 - Weather cover
 - Wishbone crutch holder
 - Additional front panel shroud inserts

• Cell phone holder

- Forearm crutch holder
- Oxygen tank holder
- Quad cane holder